

# jura.

#### Professional fine foam frother / Fine foam frother

⚠ These instructions apply to the **professional fine foam frother** and the **fine foam frother**.

The fine foam frothers can be fitted to all JURA machines featuring the Connector System<sup>®</sup>.


### Dismantling and rinsing the fine foam frother

The fine foam frother must be **dismantled and rinsed daily** if milk has been prepared to make sure it functions perfectly and also in the interests of hygiene.

- ► Carefully pull the fine foam frother off the Connector System<sup>©</sup>.
- ► Dismantle the fine foam frother into its individual parts.



Professional fine foam frother



Fine foam frother


- Rinse all the parts of the fine foam frother thoroughly under running water.
- Re-assemble the fine foam frother.
  - i Ensure that all individual parts are correctly and firmly connected to ensure optimum operation.
- ► Firmly attach the fine foam frother to the Connector System<sup>©</sup>.

### Cleaning the fine foam frother

The fine foam frother must be **cleaned daily** if milk has been prepared to make sure it functions perfectly and also in the interests of hygiene. To do this, proceed as described in your machine's instructions for use.

i Only use original JURA Cappuccino Cleaner. This is available from specialised dealers.

## Stages of the professional fine foam frother



www.jura.com